

# 

#### Tile Series Button Panel 2.0 (Plastic/metal version)

Product name	Buttons	Model No.
Tile Series Button Panel 2.0 (Plastic & metal versions)	1 Button Panel A	HDL-MP1B/TILE.48
	1 Button Panel B	HDL-MP2S/TILE.48
	2 Buttons Panel A	HDL-MP2B/TILE.48
	2 Buttons Panel B	HDL-MP4S/TILE.48
	4 Buttons Panel A	HDL-MP4B/TILE.48
	4 Buttons Panel B	HDL-MP4B-A/TILE.48
	Frames	HDL-MP1-EC/TILE.48

## buspro

Datasheet

Issued: May 24, 2021 File Edition: E



п

Ш



ф ф (у ф

63

m

п

ш

Figure 6. 4 Buttons Panel B

Figure 4. 2 Buttons Panel B




Figure 5. 4 Buttons Panel A

Figure 6-1. 1 Button Panel A/1 Button Panel B





Figure 6-2. 4 Buttons Panel A/ 4 Buttons Panel B




2 Buttons Panel A/2 Buttons Panel B

Figure 8. Dimensions - Metal version

90mm

2 Buttons Panel A/2 Buttons Panel B Figure 7. Dimensions - Plastic version



**Overview** 

Tile series Button Panel 2.0 (See Figure 1-6) contains 1/2/4-button panels, both plastic and metal versions. Icons and text of each button supports laser labelling. With built-in RGB backlight for each pushbutton, the color and brightness level can be set by HDL Buspro Setup Tool or manually set on the panel. The panels support controls of lighting, curtains, scenes, music, etc.

## **Functions**

- Built-in temperature sensor
- Built-in proximity sensor
- Icons and text of each button support laser labelling.
- Adjustable backlight brightness level via HDL Buspro Setup Tool or manual setting on the panel
  Button modes: Single on/off, Single on, Single off, Combination on, Combination off, Combination on/off, Double click/single on/off, Double click/combination on/off, Momentary, Short/long press, Short press/long momentary.
- Control types: Scene, Sequence, Timer Switch, Universal Switch, Single Channel Lighting Control, Broadcast Scene, Broadcast Channel, Curtain Switch, GPRS Control, Panel Control, Security Module, Music Control, General Control, etc.
- Button lock function.
- Online update via HDL Buspro Setup Tool.

### **Important Notes**

- Two buttons can be combined into one; for instance, A1 & A5 or A2 & A6 in Figure 6-2.
- The panel should be mounted on the wall box with power interface.
  - It is recommended to connect wires in hand-in-hand.
  - It is recommended to use dedicated HDL Buspro cable.

## **Product Information**

1 Button Panel A/1 Button Panel B - See Figure 6-1 4 Buttons Panel A/4 Buttons Panel B - See Figure 6-2 Dimensions - See Figure 7 - 9 Components - See Figure 10

1. Button: Control targets.

2. RGB backlight: Color and brightness level can be set.

- 3. Icons & text: Support laser labelling.
- 4. HDL Buspro bus connector

Lock/Unlock panel: Short press button A1 and A4 (see Figure 6-1, 6-2, 7 and 8) simultaneously to lock/ unlock the panel.

**Backlight color setting:** Press button A2 and A3 (see Figure 6-1, 6-2, 7 and 8) simultaneously for 5 econds, and the panel enters color selecting mode. Pressing button A2 mean selecting previous color from local color library, while pressing button A3 means selecting next color. The color will be finally determined if no operation is done within 20 seconds.

**Programming mode:** Press Button A3 (HDL-MP1B/TILE.48, HDL-MP2S/TILE.48, MP2B/TILE.48, MP4S/ TILE.48) for 3 seconds, all backlights turn red and the panel enters programming mode.

Press any button (HDL-MP4B/TILE.48, MP4B-A/TILE.48) for 15 seconds until all backlights flash and turn blue, and the panel enters programming mode.

**Upgrade mode:** Press Buttons (HDL-MP1B/TILE.48, HDL-MP2S/TILE.48, MP2B/TILE.48, MP4S/TILE.48: Button A3 and A4; HDL-MP4B/TILE.48, MP4B-A/TILE.48: Button A2 and A3) simultaneously before powered on, release the buttons after being powered on for 3 seconds, then the panel enters upgrade mode.

## Safety Precautions

- The installation and testing for the product must be carried out by HDL Automation Co., Ltd. or its appointed service agencies. The electric construction shall comply with local laws and safety regulations.
- The device should be wall box mounted. HDL will not be responsible for any consequence caused by the inexpert or faulty installation and wiring methods, which are not in accordance with the instructions contained in this operating instruction.
- Please do not privately disassemble or replace any parts of the product. Otherwise, it may cause mechanical fault, electric shock, fire or personal injuries.
- Please contact our after-sales departments or our designated service agencies for your maintenance service. Product failures caused by private disassembly are not subject to this warranty.

## **Package Contents**


Panel\*1 / Datasheet\*1

Figure 9. Dimensions - Side View

Figure 10. Components - Back View

## **Technical Data**

#### **Basic Parameters**



d p

ç

3 gang

Figure 13. Vertical installation

Gang

2 gang

3 gang

4 gang

2 gang

3 gang 4 gang

2 gang

۹.Þ

ò

4 gang

Dimensions

176\*90\*11(mm) 262\*90\*11(mm)

348\*90\*11(mm)

172\*86\*11(mm)

258\*86\*11(mm)

344\*86\*11(mm)

Working voltage	12~30V DC	
Working current	HDL-MP1B/TILE.48: 9.5mA/24V DC HDL-MP2S/TILE.48: 13.4mA/24V DC HDL-MP2B/TILE.48: 13.4mA/24V DC HDL-MP4S/TILE.48: 13.5mA/24V DC HDL-MP4B/TILE.48: 13.5mA/24V DC HDL-MP4B-A/TILE.48: 13.5mA/24V DC	
Communication	HDL Buspro	
Cable diameter of Buspro terminal	0.6-0.8mm	
External Environment		
Working temperature	-5°C~45°C	
Working relative humidity	≤90%	
Storage temperature	-20°C~60°C	
Storage relative humidity	≪93%	
Specifications		
Dimensions	Plastic version: 86×86×11(mm) Metal version: 90×90×11(mm)	
Net weight	Plastic version: 64g Metal version: 110g	
Housing material	Plastic version: Flame retardant PC Metal version: Aluminum alloy	
Installation	Wall box (See Figure 11)	
Protection rating (Compliant with EN 60529)	IP20	

#### Approved

CE	

#### RoHS

## HDL Buspro Cable Guide

HDL Buspro Cable
Yellow
White
Black
Red

## Installation

Product installation (Take HDL- MP4B/TILE.48 as an example)

#### Installation - See Figure 11

Step ①: Install the wall box in the wall.

Step 2: Secure the power interface to the wall box with screws.

Step ③: Install the panel on the power interface.

Step ④: Install the frame around the panel.

#### Horizontal installation - See Figure 12

Vertical installation - See Figure 13

#### Technical support

E-mail: hdltickets@hdlautomation.com

Website: https://www.hdlautomation.com

©Copyright by HDL Automation Co., Ltd. All rights reserved. Specifications subject to change without notice.

20

2 gang

3 gang

4.0

4 gang

Product name

2/3/4-gang frames

ò

ò

Figure 12. Horizontal installation

Plastic panels can be only installed horizontally.

Notes: Metal panels can be installed either horizontally or vertically.

Frame Types

Metal

Plastic